NOTICE D'UTILISATION **AREL**

• Directions for use • Manual de instrucciones

AREL [mm]	X1	X2	X3	Y	C	B	A
AREL RM 2	990	950	900	170	57	245	1245
AREL RL 2	1290	1250	1200				1545
AREL RM 1	990	950	900	85	57	160	1245
AREL RL 1	1290	1250	1200	85	57	160	1545



Attention! The lighting unit may only be assembled by a skilled firm or by person with electrotechnical qualification.

The light source of this luminaire is not replaceable, when the light source reaches its end of life the whole luminaire should be replaced.
The warranty period of this product is 24 months from the purchase date. The warranty doesn´t cover damage caused by improper handling.

NOTICE D'UTILISATION **AREL**

• Directions for use • Manual de instrucciones

AREL [mm]	X1	X2	X3	Y	C	B	A
AREL RM 2	990	950	900	170	57	245	1245
AREL RL 2	1290	1250	1200				1545
AREL RM 1	990	950	900	85	57	160	1245
AREL RL 1	1290	1250	1200	85	57	160	1545



Attention! The lighting unit may only be assembled by a skilled firm or by person with electrotechnical qualification.

The light source of this luminaire is not replaceable, when the light source reaches its end of life the whole luminaire should be replaced.

Attention! les luminaires doivent être posés par des sociétés spécialisées ou par des personnes compétentes ayant le diplôme d'électrotechnicien.